Power on/off headset:

To turn **on** the headset rotate the earcups outward.

To turn **off** rotate the earcups inwards instead. You can then fold the headset completely and place back in storage case.

Connect to Laptop:

Use the **included USB Cable**. Plug the *micro USB end* into the headset and then plug the *USB* end into the Laptop USB port. The headset will now work with your laptop and start charging.

It is essential that you return the included USB cable with the headphones.

Enable / Control Active Noise Cancellation (ANC) :

You can control the active noise cancellation with the **ANC Switch** located on the side of the headset.

- **Adaptive Mode:** when switch is in **middle** position ANC is in *adaptive mode,* in this mode the headset will automatically adjust the level of noise cancellation based on the level of noise in your environment.
- **ANC OFF:** when switch is downmost position ANC is *off*.
- **Constant ANC:** when switch is in upmost position ANC on in *constant mode*, in this mode enables contestant noise cancellation.

|	
	Turns ANC Maximum mode on
	Turns Adaptive ANC mode on; adjustable via the EPOS Connect app
	Turns ANC off

Adjusting the volume:

On headset swipe **up** or **down** to increase of decrease the volume.

Depending on the length if the swipe, you can adjust the volume in smaller steps (short swipe) or in larger steps (long swipe). You will hear a double beep when the minimum or maximum is reached. To protect hearing when you switch the headset back on, very high volume levels are reset to a moderate level when switching off.

Alternatively you can adjust the volume on your device.

Muting the microphone:

On headset swipe **backward** to mute or **forward** to unmute the microphone. You will hear a tone.

Returning / Storage of Headphones:

- Turn the headset of off position.
- Fold the ear cups inwards towards the headband.
- Store the headset and USB cable in the case and into the cardboard box.